


簡単着物  
セパレナ  
sepalena

Easy to dress in Kimono by yourself!  
Separate Kimono will enrich your daily life!

How to put on a Kimono Obi

Items to be prepared



Obi sash position  
may come to the left


01. Adjust the rubber belt length

Prepare the Kimono Obi. Wrap the rubber belt around your waist, and adjust its length a little tightly with the buckle. Otherwise, Kimono Obi will be loose.




02. Prepare the Obimakura

Wrap the Obimakura with an Obiige, layer it at the inside of Obimakura.




03. Set the Obimakura

Put the wrapped Obimakura through the rubber belt loop to hold it inside the bow.




04. Fasten the rubber belt

Wrap the rubber belt around the waist and hook it at the front.




05. Wrap the Obi

Hold the Obi with the left hand, and insert Obiita into the crease behind the Obi. Wrap it around the waist to bring the end of Obi backward.




06. Adjust the Obi length

Put through the right hand into the opening (A) behind the back bow, and pull out the end of Obi, and bring it to the right side. While holding the bottom left, fix the belt tight by pulling it well toward the right side.




07. Fasten the Obi

After letting Obi go through the fixing band, fold back the obi at the purple vertical line in the picture, and tuck the end of Obi into the opening (B) behind the back bow.



08. Tie the cords

Wrap the Obi with the cord on Obimakura, and keep up the Obimakura tightly against your back. Tie the cords in the front, and tuck the extra cord behind the Obi.



09. Straighten the Obi

Tie the Obiage, and tuck its knot behind the Obi. It looks beautiful by letting some Obiage show from underneath the obi in the front.

Complete the Kimono Obi by decorating it with Obi broach.

We recommend that you will NOT do machine washing. At the cleaning, spread a little spray water, and put a cotton towel over it. Air dry outdoors on a hanger away from direct sunlight.